

## **SUBSTITUTE SPECIFICATION**

### **ENZYMES AS CORROSION INHIBITORS BY REMOVAL OF OXYGEN DISSOLVED IN WATER**

5

This is an application filed under 35 USC 371 of  
PCT/GB2005/000813.

The invention relates to a new process for water de-  
10 oxygenation, for application in aerosol products. The  
process involves the use of an enzymatic system based on  
an oxidase enzyme a substrate for the oxidase enzyme and  
catalase. These two enzymes consume oxygen by a two step  
reaction with the substrate and hydrogen peroxide, which  
15 is formed in the first reaction.

Corrosion reactions take place in the presence of  
oxygen, oxygen dissolved in water is responsible for can  
corrosion in aqueous based formulations within aerosol  
20 containers. Currently a number of techniques are used to  
minimise corrosion in aerosol cans, for example, by the  
use of corrosion inhibitors or by an oxygen displacement  
process using nitrogen gas. We have found that corrosion  
is severely retarded if oxygen is substantially removed  
25 from the water present in the aerosol can.

Examples of products found in aerosol cans are air  
care products, household products, fabric care, waxes,  
polishes, insecticides, ironing aids, fabric refreshers  
30 and carpet cleaners.

The aerosol canister is metal, preferably steel or  
tin coated steel.

The world market trend is to move towards aerosol formulations containing more water. This is due mainly to regulatory issues: the reduction of the volatile organic content (VOC) level in aerosol products has involved a  
5 reduction in the amount of solvent of many products and an increase in the water content.

When aerosol compositions contain less than 50 ppm of water, corrosion of the aerosol can is not generally a  
10 serious problem. However, if the water content is more than 50 ppm in the aerosol composition then corrosion is more likely to occur.

Many corrosion inhibitor systems have been developed  
15 for facing these new regulatory requirements. Examples of these products are borates, benzoates, molybdate, special surfactants (such as sodium lauroyl sarcosinate), sodium nitrite and morpholine and silicates. Usually an acceptable control of the corrosion during the product  
20 life of the aerosol canister (around 2 years) is built in to the composition. The above corrosion inhibitors tend to interact with the aerosol canister's surface providing protection against corrosion.

25 There also can be negative effects of corrosive de-tinning on the performance of the product. The yellow tin corrosion complex may remain especially when sprayed onto white surfaces. White fabrics or carpets can remain coloured by the liquids of aged aerosol products. Other  
30 considerations relate to certain stains like coffee, tea and wine that contain cationic metals. These metals can form brown coloured complexes with tin hydroxyl, causing

an evident negative effect of the cleaning formulation onto overall cleaning performance.

Therefore, there is a need to identify better ways  
5 to prevent corrosion in aerosol canisters.

Corrosion is an electrochemical process. All corrosion reactions are started by the presence of water and oxygen. Oxygen is a direct participant in the  
10 corrosion reaction, acting as a cathode-accepting electron.

Dissolved oxygen present in water based formulations within aerosols is one of the most important factors  
15 influencing the rate of corrosion for all metals.

Many corrosion inhibitors have been identified in the prior art, but none really halt dissolution of the tin layer in tin-plated aerosol cans over the two years  
20 standard can life, they merely slow it down. Even resin lacquered tin-plated cans generally need an effective corrosion inhibitor system.

T.Godfrey, J.Reichelt: Industrial Enzymology, Nature  
25 Press 1983 - Chapter 4.2: G.Richter - Glucose Oxidase, US 5,980,956, EP 0818960 & EP 0835299 describe the use in the food industry and especially in canned soft drinks industry of an enzymatic system based on glucose oxidase and catalase as an antioxidant primarily to prevent  
30 changes in colour and flavour of foods products both during processing and in storage.

US 4,414,334 describes the use of alcohol oxidase and catalase to remove oxygen dissolved in aqueous liquids and discloses the use of such systems in foodstuffs and water distribution systems.

5

Currently a vacuum process is used to remove oxygen during aerosol product manufacture, which does reduce the oxygen content in the aerosol can. The reduction is only in the aerosol can head space and has little effect on the deoxygenation of the liquid phase. For liquid phase  
10 deoxygenation currently used is a method called nitrogen stripping, a process that is quite expensive. The process of the present invention can reduce the oxygen content in the aerosol can during manufacturing and even, during  
15 product storage.

We have found that the use of an oxidase enzyme and a substrate for the oxidase enzyme combined with catalase effectively reduces the rate of corrosion in aerosol cans  
20 by reducing almost to zero the concentration of oxygen dissolved in the water.

The process of the invention is particularly effective at neutral and acidic pH. The deoxygenating  
25 process requires a longer time at alkaline pH: this is not necessarily a problem since the enzymatic system will continue to work over time if placed in the aerosol product.

30 Other advantages of enzymes are that they are very effective even at low concentration, starting from 0.01 ppm of enzyme and 50 ppm of substrate. The enzymes are also compatible with aerosol formulations and have a low impact on the overall formulation cost.

We present as a feature of the invention an aerosol product comprising a sealed metal canister containing an aerosol composition comprising an oxidase enzyme and a substrate for the enzyme. Preferably catalase is also added.

Alternatively we present as a feature of the invention a method of deoxygenating an aerosol produce comprising filling an aerosol canister with an aerosol composition, an oxidase enzyme and a substrate for the oxidase enzyme and, in any order, filling the aerosol canister with propellant and sealing the aerosol canister.

Preferably a catalase is additionally added into the canister.

Alternatively, we present as a feature of the invention use of an oxidase enzyme and a substrate for the oxidase enzyme as a corrosion inhibiting system for aerosol products. Preferably catalase is also used.

Suitable oxidase enzymes are those classified under enzyme classification E.C.1.1.3 (Acting on the CH-OH group of donors with oxygen as acceptor) and include one or more of the following. Not all enzymes produce hydrogen peroxide as a product of the reaction. Therefore in a preferred feature of the invention when such enzymes are used the presence of catalase is not required, for example nucleoside oxidase.

Preferred enzymes are selected from one or more of the following; Malate oxidase, Glucose oxidase, Hexose oxidase, Cholesterol oxidase, Aryl-alcohol oxidase, L-gulonolactone oxidase, Galactose oxidase, Pyranose  
5 oxidase, L-sorbose oxidase, Pyridoxine 4-oxidase, Alcohol oxidase, Catechol oxidase, (S)-2-hydroxy-acid oxidase, Ecdysone oxidase, Choline oxidase, Secondary-alcohol oxidase, 4-hydroxymandelate oxidase, Long-chain-alcohol oxidase, Glycerol-3-phosphate oxidase, Xanthine oxidase,  
10 Thiamine oxidase, L-galactonolactone oxidase, Cellobiose oxidase, Hydroxyphytanate oxidase, Nucleoside oxidase, N-acylhexosamine oxidase, Polyvinyl-alcohol oxidase, Methanol oxidase, D-arabinono-1,4-lactone oxidase, Vanillyl-alcohol oxidase, Nucleoside oxidase, D-mannitol  
15 oxidase and Xylitol oxidase.

A preferred enzyme is Glucose Oxidase. Glucose Oxidase is a highly specific enzyme derived from the fungi *Aspergillus Niger* and *Penicillium*. Glucose oxidase  
20 is an oxidoreductase, that catalyses the oxidation of D-Glucose to gluconic acid using molecular oxygen and releasing hydrogen peroxide. Glucose oxidase has a molecular weight of 192000, an optimum temperature of 30-50°C and optimum pH of 4.5-6.5. It is inhibited by  
25 heavy metal salts, preferably a chelating agent may be added to the aerosol composition, and sulfhydryl chelating agents. The effective amount enzyme needed is from 0.001 ppm to 500 ppm, more preferably between 0.01 and 50 ppm.


30 Catalase is a common enzyme present in the cell of plants, animals and aerobic bacteria. It promotes the conversion of hydrogen peroxide to water and molecular oxygen. This reaction is very specific and very fast:

catalase has one of the highest turnover rates for all enzymes. Catalase is inhibited by urea, freezing and sunlight under aerobic conditions. The effective amount of enzyme needed is from 0.001 ppm to 500 ppm, more preferably between 0.01 and 50 ppm.


The reaction is:



10



Total reaction:



By forcing the equilibrium of the reaction by an excess of substrate to the oxidase enzyme, it is possible to end up with a final oxygen content close to zero.

20

Therefore, the concentration of substrate needed in order to increase the velocity of the first reaction is ideally greater than the  $K_m$  of the enzyme selected ( $K_m$  is the Michael's constant and is the affinity of the enzyme for the substrate, i.e. the concentration at which 50% of the enzyme binding sites are occupied). Typical  $K_m$ 's are  $10^{-1}$  M to  $10^{-6}$  M.

An important feature of the invention is a substrate for the oxidase enzyme used, this may already be present in the composition to be packaged in the aerosol canister or it might be added. A preferred substrate is D-glucose.

The performance of the new corrosion inhibitor system has been evaluated first by measuring the dissolved oxygen reduction (Oxy-meter) in a typical conditions and then by a quick method for the evaluation of corrosion, the jar method, using as fill formulation using tap water treated or not with the enzymatic system on a standard epoxy coated piece of aerosol can.

10 OXY-METER EVALUATION

A 5L glass beaker is used in this test.

4L of tap water are added into the beaker and warmed to 40°C.

15 pH of the solution is measured and adjusted to desired value. Dissolved oxygen (DO mg/L) pH and Temperature (°C) are measured through an Oxy-Meter YSI 556 MPS.

The time zero DO value is collected, D-Glucose is added to the solution and immediately after the enzymatic system is dosed.

The reaction is then followed constantly reading the DO value until it reaches a plateau value.

25

The system is open, so no control to oxygen intake from the air is considered.

JAR METHOD:

30

50 ml glass jars with screw plugs are used in this test.



A round piece of a can is cut and applied on the internal surface of the jar screw plug. A cross is cut by a blade on the can piece in order to simulate possible defects on the can walls.

- 5 A poly tetra fluoroethylene gasket is also applied on the plug in order to guarantee a good sealing system. The jar is filled with the testing formula and it is stored in the inverted position to obtain the contact between the liquid formula and the tin plated can piece applied on
- 10 the plug.

The storage is carried out at different temperature (20°C, 40°C and 50°C) for several days up to 1 month. The storage situation is monitored after 1 day, 1 week, 2

15 weeks, 1 months and compared to reference can pieces and liquids. The can piece appearance is recorded. A recording data table with the corresponding corrosion rating is reported below:

Corrosion Rating JM	Can piece appearance
0	No difference from reference
1	Low darkening along the cut lines
2	Darkening along the cut lines
3	Strong darkening on all the can piece area
4	Darkening on all the can piece area
5	Evident darkening on all the can piece area

6	Rust
---	------

EXAMPLES:

The liquid phases are typically prepared by mixing D-  
5 Glucose anhydrous to warm 40°C tap water, adjusting the  
pH to the desired value and then adding the enzymatic  
system to start the de-oxygenation reaction.

Table 1						
Components	Ref 1	Ref 2	Ref 4	Ref 5	Ref 6	Ref 7
	ppm	ppm	ppm	ppm	ppm	ppm
D-Glucose	60 (0.006%)	250 (0.025%)	500 (0.05%)	1000 (0.05%)	1000 (0.1%)	500 (0.05%)
OxyGo 1500	0.0125	0.05	0.1	0.2	0.2	0.1
Tap Water	to 100%	to 100%	to 100%	to 100%	to 100%	to 100%
PH	7	7.8	7.1	7.1	9.1	4.9

Table 2	
Component	Description of component
D-Glucose	D(+)-Glucose anhydrous >99.5% from Fluka
OxyGo 1500	Glucose Oxidase Enzyme with Catalase side activity from Genencor
NaOH	Sodium Hydroxide, 10% solution
H2SO4	Sulphuric Acid, 9% solution

10 EXAMPLE RESULTS:

The enzymatic corrosion inhibitor system was tested for  
all formulations using an Oxy-meter evaluation and for  
formulation Ref.4, Ref.5, Ref. 6 and Ref.7 using the Jar

method. Evaluation of possible residual H<sub>2</sub>O<sub>2</sub>, due to slow action of catalase, was done for formulation Ref.4, Ref.5, Ref.6 and Ref.7.

Results:

5

Product	DO (mg/L) at 40°C (Oxy-meter evaluation)			
	Time 0	30'	60'	90'
Ref 1	4.40	4.03	3.79	3.69
Ref 2	4.24	4.12	3.42	3.18
Ref 4	4.31	2.06	1.40	1.10
Ref 5	4.51	1.05	0.84	0.60
Ref 6	4.50	2.76	2.01	1.49
Ref 7	3.80	1.55	1.48	1.25

Product	Corrosion rating (Jar method)								
	20°C		1 day		1 week		2 weeks		1 month
	uncut	cut	uncut	cut	uncut	cut	uncut	cut	
Ref 4	0	0	0	0	0	0	0	1	
Ref 5	0	0	0	0	0	0	0	1	
Ref 6	0	0	0	0	0	1	0	1	
Ref 7	0	0	0	0	/	/	/	/	
Tap Water	0	6	0	6	0	6	1	6	

40°C	1 day		1 week		2 weeks		1 month	
	uncut	cut	uncut	cut	uncut	cut	uncut	cut
Ref 4	0	0	0	0	0	1	0	1
Ref 5	0	0	0	0	0	1	0	1
Ref 6	0	0	0	0	0	1	0	1
Ref 7	0	0	0	0	/	/	/	/

Tap Water	0	6	0	6	0	6	2	6
-----------	---	---	---	---	---	---	---	---

50°C	1 day		1 week		2 weeks		1 month	
	uncut	Cut	uncut	cut	uncut	cut	uncut	cut
Ref 4	0	0	0	0	0	0	0	1
Ref 5	0	0	0	0	0	1	0	2
Ref 6	0	0	0	0	0	2	0	2
Ref 7	0	0	0	0	/	/	/	/
Tap Water	0	6	0	6	0	6	2	6

Product	H2O2 % formation			
	10'	30'	60'	90'
Ref 4	0.01	0.00	0.00	0.00
Ref 5	0.00	0.00	0.00	0.00
Ref 6	0.03	0.00	0.00	0.00
Ref 7	0.01	0.00	0.00	0.00

- 5 The above results show that the two enzymatic reactions take place relatively quickly, so the H<sub>2</sub>O<sub>2</sub> formed in the first step is consumed in the second step.